

**LISEGA plug-in
for
AutoCAD
and
AutoCAD Plant 3D**



Plugin version 11.0.0.5

Inhaltsverzeichnis

System requirements	3
UPDATE – IMPORTANT NOTE	3
Installation	3
New feature (2D library)	3
UI changes	3
General Plugin information	4
Insertion of LISEGA supports	4
Variant 1:	4
Configurations available	11
Variant 2: Import of L3D files	13
Commands available	14
LSET	14
LIPART3D	15
LIPART2D	15
LILICAD	15
LILICAD1	15
LILICAD2	15
LILICAD3	15
LILICAD4	15
LILICAD5	15
LILICADmod	15
L3DIMP or -L3DIMP	16
Attachment	17
AutoCAD menu extension, tool box and ribbon for plug-in	17
Index	18

System requirements

- AutoCAD Version 2017 or higher
- AutoCAD Plant 3D Version 2017 or higher
- **LICAD Version 11.0**

UPDATE – IMPORTANT NOTE

An already existing version of the plugin must be deinstall.

An update installation is not supported!

Installation

Start the installation program and follow its instructions.

This version of the plugins is using the new AutoCAD plugin technique. This requires that the files are stored in folder that AutoCAD is looking at for plug-ins.

AutoCAD will load the plugin automatically if it's recognized.

This doesn't require neither configuration nor manual loading plugins.

The installation directory is:

- %ProgramFiles%\Autodesk\ApplicationPlugins\ LISEGA 3D Plugin V104.bundle


Hint: %ProgramFiles% is normally „C:\Program Files“

New feature (2D library)

This plugin version contains the 2D library that was previously separate available!

UI changes

There is a ribbon control called “LISEGA Tools” installed:



It contains all available commands of the plugin.

General Plugin information

The plugin is identical to the BricsCAD plugin. That means that the same commands are available in the AutoCAD plugin as in the BricsCAD plugin. The BricsCAD Plugin does currently not include the 3D part library.

Insertion of LISEGA supports

Two variants are available for placing LISEGA components.

The first possibility is the interactive process by which LICAD¹ program is directly accessed during the creation of the support in the 3D model.

The second possibility is the import² of L3D files created with LICAD. The information contained in the L3D file is then transferred to corresponding 3D objects.



Variant 1:

Example of the command „LICAD“ of the plug-in Licad4Plant3D_V18 under Plant 3D 2011.


An empty drawing file is used here to draw attention to the essential points. A support is to be placed between the two 3D crosses displayed here.

1 For this, the LICAD program must be installed on the computer

2 The installation of LICAD is not necessary for this.




Configuration 1 is used. This can be carried out by the command „LICAD“ and subsequent request for the configuration number or by the command „LICAD1“, which already has the number in the name.




As the “LICAD1” command was activated, the request for the configuration number is skipped over.


The question is then put as to whether the support is to be free or placed on the piping.




As an empty drawing was used in the example, the „on pipe“ option does not function, so the „free“ option was chosen. During the pipe center point input, the positioning of the clamp in the direction „X“ or „Y“ axis can be decided on. The specification is the „X“ direction.



After the entry of „Y“ instead of a point the clamp is correspondingly displayed rotated by 90° (see the two following illustrations).




After confirmation of the entry the clamp rotates in the „Y“ axis direction.




By entering the letter „X“, and following confirmation, the positioning of the clamps is again carried out in the direction of the X axis. Now the pipe center point is determined here on the intercept of


the lines of the lower star.




After that the upper attachment point of the support to the intercept of the lines of the upper star is determined.



After confirmation of the structural attachment point the LICAD program is automatically started. There the relevant data available (the configuration selected in LICAD is No. 13, the elevation numbers are entered) are already in the input fields. As the free mode was selected, no pipe data are on hand. In the „on pipe“ mode the data for the diameter, temperature and insulation would have been taken over.




The missing data needed by LICAD for the design can now be simply supplemented.



On completion of all inputs, only the button at the bottom right with the green arrow now has to be pressed. LICAD then assembles the components required and supplies the information to the plug-in.

The plug-in reads this information and generates from it the whole support out of the individual components composed from 3D bodies.

The result of this example looks as follows:



Configurations available

For the commands LICAD, LICAD1, LICAD2, LICAD3, LICAD4 or LICAD5 the following configurations are currently available.


Configuration 1:

(Simple suspension for horizontal pipes)




Configuration 2:


(Clamp base / pipe shoe for horizontal pipes)




Configuration 3: (Clamp base with spring support for horizontal pipes)




Configuration 4 (for horizontal pipes):




Configuration 4 (for vertical pipes):



Configuration 5 (for horizontal pipes):




Configuration 5 (for vertical pipes):




Variant 2: Import of L3D files

Command input:




1. An „open file“ dialog appears, in which files of the type „LISEGA support information (*.L3D)“ can be selected.



Select a file and press the „open“ button.

2. The plug-in reads the information from the L3D file and creates from it the 3D model of the support.



Commands available


The commands are now called different between the two plug-ins. For AutoCAD plugin the commands start with “L4AL10” and for the Plant3D plugin the command names start with “L4PL10”.

This change was necessary to allow both plugins to be loaded in Plant3D.

The actual commands have the same name in both plug-ins:


LISET

The settings for the plug-in can hereby be displayed and if necessary altered.




LIPART3D

With the aid of this command individual components from the LISEGA catalog can be inserted into the 3D model.



LIPART2D

With the aid of this command individual 2D views of a part from the LISEGA catalog can be inserted into the 2D drawing.



LILICAD

LILICAD1

LILICAD2

LILICAD3

LILICAD4

LILICAD5

LILICADmod

These commands always start the LICAD program after requesting the necessary information in AutoCAD/Plant 3D. A distinction is only made with regard to the preselection of the configuration.

L3DIMP or -L3DIMP

These two commands import LISEGA supports available in the shape of L3D files.


The command „...L3DIMP“ opens an „open file“ dialog. The „-...L3DIMP“ command is the command line variant of the command „...L3DIMP“ and queries the file name in the command line.

It is necessary that a support is created, stored and exported beforehand as an L3D file with the LICAD program. (See attachment - LICAD creation of a support, export of a stored support as L3D file)

Attachment

AutoCAD menu extension, tool box and ribbon for plug-in

The following ribbon control is available:



Index

...L3DIMP	LICAD
-...L3DIMP	LIPART2D
2011	LIPART3D
AutoCAD	LISEGA
configuration	menu extension
Configuration	ribbon
individual components	System requirements
L3D files	tool box